

9004 and 9007 Headlight Additional Installation Tips.

- Many 9004 and 9007 Headlights use a retaining collar to hold the bulb in place.
- Reuse the Factory Collar, or replace with a Slim Collar such as a Dorman #42415.
- If using the factory collar, you may need to trim it down in length to clear the LED heatsink. This can be done with a fine-tooth hacksaw or rotary tool.
- To install the collar, you will remove the front flange on the LED bulb. There is a small hex screw that positions the flange, remove the flange and pull the flange off the front of the LED.
- Install the collar, then replace the flange. Note that the flange can be install in four different positions, position the flange so that when the light is back in the fixture, the LEDs face left and right, not up and down.



Dorman HELP! 42415 Headlamp Bulb Retainer

OR

