

1. Cut all wires from the ballast
  2. Ground side: take one white wire and one red wire from sockets, and connect it to the white wire coming into the fixture from the coach. Use the extra white wire supplied in the kit to extend it.
  3. Put tape over the end of the unused white and red wire from these sockets.
  4. Leave the black wire from the coach that goes to the switch alone.
  5. Power side: there is a white wire that goes from socket to socket, leave it alone.
  6. Take the other white wire from the upper right socket, and the red wire from the lower right socket, and connect them to the red wire coming from the switch.
- That's it.

