

# T8 RV Luminare



1. **Cut all wires from ballast**
2. **Strip and Connect 3 wires marked "A" together**
3. **Strip and connect 3 wires marked "B" together (we will send an extra length of wire with tube to connect between for length)**
4. **Tape or Cap off 2 wires marked "T"**

