



A. Cut this Black, Red, and Blue wire away from the ballast, strip them and connect them all together.

B. Cut This White wire and all of these Red and Blue Wires away from the ballast. Strip and connect the white wire to one blue and one red wire. The remaining red and blue wires just put a little tape on each end.