

## WK-SS1AP Accent LED Installation Guidelines



Every Installation is Different. The following are general guidelines for installation, not specific details. Basic 12 Volt DC wiring is required.

- Choose an installation location.
- Before drilling any holes, ensure the following:
  - You can get 12 volt fused and switched power to the location
  - There are no wires, tubes, hoses or other obstructions behind the mounting area
  - You have proper tools to drill a hole in the surface



- The LED body is slightly larger than a 5/8 drill bit (not included).
- For a tight fit, drill a 5/8 hole, then ream or file the hole to size. This will give you a secure tight fit.



- Drill a pilot hole. Check again behind the hole that there are no obstructions, the exit point will be easier to see.



- Drill the 5/8" hole. Depending on the surface, take necessary precautions. Carpet, sharp and slow. Fiberglass, low pressure, if you feel necessary protective tape over gel coat, etc.
- Ream or File the whole slightly larger for snug fit to LED. Go slowly and measure several times.
- On final install, Clear RTV Silicone (not included) can be used for seal LED and hold in place if necessary.
- Wire lights to fused and switched source. <5 amp fuse suggested. Red = power, Black = ground.
- Tie all wires securely out of the way with cable ties or tape (not included).