



The Black Wires from the drivers need to go to the sockets at the other end of the fixture.

The Blue wires from the drivers need to go to the other end of the fixture too and connect to the black wire to the coach along with the second wire from the festoon.





#9 and #10 White Wires attach to the sockets at this end. These need to connect to the Black Wires from the drivers. Contrary to the general instruction sheet that came with the tubes, you can connect these two white wires and 2 black driver wires all together (you cannot do this to the wires at the other end of the fixture)

